



PARTS LIST		
DESCRIPTION	PART NUMBER	QTY
CONTROLLER BOX	DUO2.CAN	1
SENSOR OPTION LEFT	SENSOR OPTIONS	1
SENSOR OPTION RIGHT	SENSOR OPTIONS	1
JOYSTICK	A.RS.082 (Optional)	1
HYDRAULIC CABLE (5m)	A.RS.080	1
CAN CABLE (5m)	A.RS.110	1
CAN CABLE (2.5m)	A.RS.111	1
DUO2-IB.GNSS CORD (5m)	A.RS.096	1
INTERFACE BOX	IB.DUO2.CAN	1
POWER CABLE (6m)	A.RS.001.NC	1
GNSS INTERFACE BOX	IB.GNSS	1
HIRSCHMANN CONNECTORS	GDM 3009 BLACK (Optional)	2 or 4




CAN CABLE OPTIONS	
A.R.S.111	(2.5m)
A.R.S.110	(5.0m)
A.R.S.107	(10.0m)
A.R.S.106	(CURLY CORD)
	1.7m un-stretched
	8.5m stretched



OPTIONAL 8P - 8S
CAN CORD ADAPTOR
(P.CONN.018)
for extending CAN cables

LASER RECEIVER MODELS	
R.ULS.CAN	
R.ULS.MM.CAN	
R.ULS.MM.500	
R.ULS.MM.1000	

ON ATTACHMENT



RevNo	Revision note	Date	Signature	Checked	Tolerances	Path: X:\Graphical Work\Setup Diagrams\Set-up diagrams for website				
1	Rearranged to be consistent with the rest of the setup diagrams.	22/01/21	N.A.	D.R. & C.R.	Unless Stated:	Material:	Finish:			
	Updated the template.				xx.x = +/- 0.1 xx.xx = +/- 0.05 xx.xxx = +/- 0.02	Drawn by: N.A.	Checked by: D.R. & C.R.	Unit:	Date: 22/01/21	Scale: NTS
							Title: SETUP DIAGRAM FOR DUO2 WITH HYDRAULIC BREAKAWAY JUNCTION BOX			
							Drawing No:		Version:	Sheet: 1